


<p>(1) TOP</p> <p>1PC</p>	<p>(2) Modesty Panel</p> <p>1PC</p>	<p>(3) NAP-265</p> <p>1PC</p>	<p>(4) NAP-271-1</p> <p>1PC</p>	<p>(5) NAP-271-2</p> <p>1PC</p>	<p>(A) Dowel</p> <p>8PCS</p>	<p>(B) Cam Pin</p> <p>4PCS</p>
<p>(C) Cam Lock</p> <p>4PCS+1</p>	<p>(D) Leg leveller</p> <p>7PCS</p>	<p>(p) Adhesive Cam Cover</p> <p>4PCS</p>	<p>(E4) Wood Screw</p> <p>28PCS+1</p>	<p>(E9) Wood Screw</p> <p>8PCS+1</p>	<p>(S0) Corner Bracket</p> <p>5PCS</p>	<p>STEP 1</p>
<p>STEP 2</p>		<p>STEP 3</p>	<p>STEP 4</p>	<p>STEP 5</p>	<p>STEP 8</p>	
<p>STEP 6</p>	<p>STEP 7</p>					

BOW TOP/MODESTY SET (LAMINATE)
 (Left Or Right Application)
NAP-289
 71"W*40"D*29"H



Always lay components on A clean, soft-cushioned surface during assembly.